



TUBULAR HEATER



211 MACES ROAD, CHRISTCHURCH,
NEW ZEALAND

GUARANTEE

This heater is guaranteed against faulty workmanship or defective material for 12 months from the date of purchase, providing:

1. That the heater is used in accordance with the instructions supplied by the manufacturer.
2. That the heater has not been misused or any unauthorised alterations, modifications or substitutions made to any parts of it.
3. Liability under this guarantee is limited to free repair or replacement (at the manufacturer's options) or any part found to be defective.
4. The manufacturer shall not in any case be liable to pay for compensation of any loss or damage whatsoever sustained by the purchaser.

We recommend your heater is only serviced or repaired by the manufacturer or a suitably qualified person.

FEATURES

VERSATILE Tubular Heaters are available to suit your needs...in wide range of sizes with one, two or three tier combinations. This means you can use them virtually anywhere, from airing cupboards to wardrobes, bedrooms and hallways to factories, shops to glasshouses, nurseries to dog kennels, to wherever you need warmth.

ECONOMICAL because of their simple design and construction, Tubular Heaters are a very cost effective heating medium with low initial purchase price and inexpensive operating costs

EFFICIENT Tubular Heaters work on a low temperature convection heating method. An element totally enclosed inside the tube operates as "Black Heat", gently warming air passing over the tube to efficiently combat winter chill and dampness.

Made in New Zealand

INSTRUCTIONS

- This Tubular Heater is intended for use as a fixed heater.
- All heaters must be installed with;
 - Any shelf or ceiling a minimum distance of 75 mm above the heater surface.
 - Any side or back wall a minimum distance of 75 mm from the heater surface.
 - Only single tier heaters are to be installed in wardrobes or cupboards.
 - The door must be at least 150 mm from the heater surface.
 - There must be a clearance of at least 100 mm between any shelf installed above the heater and the door.
- The heater must be mounted with the tube in a horizontal orientation.
- The brackets provided must be used, and should be secured directly to the wall framing or floor. The brackets can be easily adjusted to any position along the heater length.
- Do not cover the heater.
- To allow disconnection, the plug or heater isolator must remain accessible.
- When installed in a bathroom, this heater must be installed so that switches and other controls are not accessible by a person in the bath or shower.
- If the supply cord is damaged, it must be replaced by the manufacturer or a suitably qualified person.
- This heater is not intended to be mounted under church benches.
- This heater must not be mounted in front of or immediately below a socket-outlet.
- This heater is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the heater by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the heater.

LAB700

Argus Heating Limited

211 Maces Road, Bromley, Christchurch 8062 • PO Box 24 363, Christchurch 8642, New Zealand
Phone +64 3 381 1363 • Fax +64 3 381 1063 • www.argusheating.co.nz • enquiry@argusheating.co.nz